

# QUICK CHANGE JAW ASSEMBLY FOR CO-AX PRESS - FORSTER PRODUCTS, INC. QUICK CHANGE JAW ASSEMBLY S-SMALL (0.343"-0.422")

[Reloading](#) > [Reloading Presses](#) > [Single Stage Presses](#)

Reloaders who use the Forster Co-Axial reloading press can take advantage of a quick-change system designed to hold shells, thanks to a set of spring-loaded jaws that contact the base of the cannelure. These self-acting jaws automatically close around the cartridge case as the press works, releasing the case once the press has done its work. Forster now offers a Quick-Change Jaw Assembly for its press, which makes swapping out these jaws for different case sizes a breeze. S-Large - holds .468" to .562" rim S-Small - holds .343" to .422" rim LS-Large - holds .531" to .625" rim LS-Small - holds .312" to .375" rim Each Forster Quick-Change Jaw Assembly allows for easy swapping of S or LS shell-holder jaws, allowing users to adjust the shell holders to accommodate cases ranging in size from .312-.625-inch shell rims. This saves an incredible amount of time when switching over to a new caliber, and it also avoids the frustration of losing springs or misplacing a spare set of shell-holder jaws. As an added bonus, with the Forster Quick-Change Jaw Assembly, there's no possibility of installing the jaws in the wrong direction, avoiding the frustration of assembling the wear plate in backwards or having a flipped jaw.



## Attributes

- Name: [FORSTER PRODUCTS, INC. QUICK CHANGE JAW ASSEMBLY S-SMALL \(0.343"-0.422"\)](#)
- Manufacturer: [FORSTER PRODUCTS, INC.](#)
- Product no.: 319000050
- Mfr. No.: 028271-202
- Delivery weight: 0.125kg
- Shipping height: 13mm
- Shipping width: 102mm
- Shipping length: 152mm
- UPC: 757253991400

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for QUICK CHANGE JAW ASSEMBLY FOR COAX PRESS
- About Us

# Safety Instruction Guide for QUICK CHANGE JAW ASSEMBLY FOR COAX PRESS

## Introduction

Thank you for choosing the Forster Quick Change Jaw Assembly for your CoAxial reloading press. This guide provides important safety information and instructions to ensure the safe and effective use of this product. Please read this manual carefully before using the assembly to understand the potential hazards and how to avoid them.

## General Safety Guidelines

- Always follow the manufacturer's instructions for installation and usage.
- Ensure that the Quick Change Jaw Assembly is compatible with your Forster CoAxial press.
- Keep the assembly out of reach of children and vulnerable individuals.
- Inspect the assembly regularly for any signs of wear or damage before each use.
- Do not use the assembly if it is damaged or malfunctioning.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling the assembly.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Ensure that the press is turned off and unplugged before installing or changing the jaws.
- Do not exceed the recommended shell rim sizes for each jaw type:
  - SLarge: .468" to .562"
  - SSmall: .343" to .422"
  - LSLarge: .531" to .625"
  - LSSmall: .312" to .375"
- Avoid placing fingers or hands near the jaws while the press is in operation.
- Do not force the jaws to hold a cartridge case that is outside the specified size limits.
- Ensure that the jaws are properly seated and secured before operating the press.

## Instructions for Installation and Usage

### 1. Installation of the Quick Change Jaw Assembly

- Make sure the CoAxial press is turned off and unplugged.
- Remove the existing jaws from the press by following the manufacturer's instructions.
- Select the appropriate Quick Change Jaw based on the size of the cartridge case you intend to reload.
- Align the new jaw assembly with the mounting points on the press.
- Secure the jaw assembly in place as per the manufacturer's guidelines.

### 2. Using the Quick Change Jaw Assembly

- Plug in the press and turn it on.
- Place a cartridge case into the jaw assembly.
- Operate the press according to the manufacturer's instructions.
- The selfacting jaws will close around the cartridge case automatically.
- Once the press completes its operation, the jaws will release the case.

### 3. Changing Jaws

- Turn off and unplug the press before changing jaws.
- Release the current jaw assembly following the manufacturer's instructions.
- Select and install the new jaw assembly as described above.

## **Disposal Instructions**

- Dispose of the Quick Change Jaw Assembly in accordance with local regulations.
- Do not dispose of the assembly in general waste if it contains hazardous materials.
- Consider recycling options where available.

## **Contact Information for Further Support**

For any questions or concerns regarding the Quick Change Jaw Assembly, please refer to the manufacturer's contact details provided with the product packaging. Always ensure to reach out for assistance if you encounter any issues or have safety concerns.

Thank you for your attention to these safety guidelines. Your safety is our priority. Enjoy your reloading experience with Forster Products!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)