


UNIVERSAL SHELL HOLDERS - LEE PRECISION #15 (AP) PRIMING TOOL SHELL HOLDER

[Reloading](#) > [Shellholders & Shellplates](#)

Universal shell holder used in most brands of reloading presses. Will not work with Lee Auto Prime. View Lee Shellholder Chart



Attributes

- Name: [LEE PRECISION #15 \(AP\) PRIMING TOOL SHELL HOLDER](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 430108700
- Mfr. No.: 90017
- Cartridge: 5.7 x 28 mm,25 Auto
- Delivery weight: 0.017kg
- Shipping height: 8mm
- Shipping width: 97mm
- Shipping length: 127mm
- UPC: 734307900175

Item details

Made in USA

Table of Contents

- Startpage
- Universal Shell Holders Lee Precision #15 (AP) Priming Tool Shell Holder Safety Instructions
- About Us

Universal Shell Holders Lee Precision #15 (AP) Priming Tool Shell Holder Safety Instructions

Introduction

Thank you for choosing the Universal Shell Holders Lee Precision #15 (AP) Priming Tool Shell Holder. This product is designed to enhance your reloading experience. To ensure your safety and the safe use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always ensure that the shell holder is compatible with your reloading press before use.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the shell holder for any damage before each use. Do not use if damaged.
- Follow all manufacturer instructions for your reloading press when using this shell holder.
- Report any unsafe conditions or incidents related to this product to the appropriate authorities.

Specific Safety Precautions for Use

- Do not use this shell holder with the Lee Auto Prime.
- Ensure that the cartridge being used is appropriate for the shell holder (5.7 x 28 mm, 25 Auto).
- Always wear safety glasses when reloading ammunition to protect your eyes from any potential hazards.
- Work in a wellventilated area to avoid inhaling any dust or particles produced during the reloading process.
- Keep your work area clean and organized to prevent accidents.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Remove any existing shell holder from the reloading press.
- Insert the Universal Shell Holder Lee Precision #15 (AP) into the shell holder socket of your reloading press until it is securely in place.

2. Usage:

- Confirm that the shell holder is properly seated in the reloading press.
- Insert the appropriate cartridge into the shell holder.
- Follow your reloading press's operating instructions to complete the reloading process.
- After use, remove the shell holder from the reloading press and store it in a safe location.

Disposal Instructions

- Dispose of the Universal Shell Holder in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is damaged, ensure it is disposed of in a manner that prevents injury to others.

Contact Information for Further Support

For any questions or concerns regarding the Universal Shell Holders Lee Precision #15 (AP) Priming Tool Shell Holder, please refer to the product packaging or the manufacturer's website for more information.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Universal Shell Holders Lee Precision #15 (AP) Priming Tool Shell Holder. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk