


UNIVERSAL SHELL HOLDERS - LEE PRECISION UNIVERSAL SHELL HOLDER R7

[Reloading](#) > [Shellholders & Shellplates](#)

Universal shell holder used in most brands of reloading presses. Will not work with Lee Auto Prime. View Lee Shellholder Chart



Attributes

- Name: [LEE PRECISION UNIVERSAL SHELL HOLDER R7](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 430108715
- Mfr. No.: 90524
- Cartridge: 32 Auto (ACP)
- Style: -
- Delivery weight: 0.022kg
- Shipping height: 15mm
- Shipping width: 97mm
- Shipping length: 127mm
- UPC: 734307905248

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for UNIVERSAL SHELL HOLDERS LEE PRECISION UNIVERSAL SHELL HOLDER R7](#)
- [About Us](#)

Safety Instruction Guide for UNIVERSAL SHELL HOLDERS LEE PRECISION UNIVERSAL SHELL HOLDER R7

Introduction

Thank you for choosing the UNIVERSAL SHELL HOLDERS LEE PRECISION UNIVERSAL SHELL HOLDER R7. This guide provides important safety instructions to ensure safe and effective use of the product. Please read this guide carefully before use to understand how to operate the shell holder safely and responsibly.

General Safety Guidelines

- Ensure that the shell holder is compatible with your reloading press. This shell holder is designed for use with most brands of reloading presses, but it will not work with the Lee Auto Prime.
- Always handle reloading equipment with care, following the manufacturer's instructions.
- Keep the shell holder and all reloading equipment out of reach of children and vulnerable individuals.
- Regularly inspect the shell holder for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- Always wear appropriate eye protection when using reloading equipment.
- Do not exceed the recommended load limits for your specific reloading press.
- Use only the specified cartridge for this shell holder: 32 Auto (ACP).
- Avoid distractions while reloading to maintain focus and ensure safety.
- Store reloading components and equipment in a secure location to prevent unauthorized access.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged.
- Locate the shell holder slot on your reloading press.
- Insert the UNIVERSAL SHELL HOLDER R7 into the slot until it is securely in place.
- Confirm that the shell holder is properly seated and does not wobble.

2. Usage:

- Refer to your reloading press's user manual for specific operational instructions.
- Place the cartridge (32 Auto) into the shell holder.
- Follow the reloading process as outlined in your press's manual, ensuring to adhere to all safety precautions.
- After use, remove the shell holder from the press and clean it as necessary.

Disposal Instructions

- Dispose of the shell holder in accordance with local regulations regarding plastic and metal recycling.
- Do not dispose of the shell holder in regular household waste if it is damaged. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's contact details provided with your product packaging. Always ensure you have the most current information regarding safety and recalls.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with the UNIVERSAL SHELL HOLDERS LEE PRECISION UNIVERSAL SHELL HOLDER R7. Always prioritize safety and adhere to local regulations when engaging in reloading activities. Thank you for your commitment to safe reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk