

ACCUWASHER GEN 2 MUZZLE DEVICE ALIGNMENT SYSTEM - PRECISION ARMAMENT ACCUWASHER AW750 GEN2 SHIM KIT - 1/2-28 .925"

[Rifle Parts](#) > [Barrel Parts](#) > [Rifle Barrel Hardware](#) > [Washers](#)

PRECISION ARMAMENT ACCUWASHER GEN 2 MUZZLE DEVICE ALIGNMENT SYSTEM The AccuWasher® Gen 2 Muzzle Device Alignment System is the ultimate solution for precise and repeatable muzzle device alignment. Unlike traditional crush washers, this mono-shim system is precision lathe-turned on both faces, ensuring a certified guaranteed circular thickness uniformity of .0001" for unparalleled accuracy. FEATURES: Precision Machined Mono-Shim: Provides exact muzzle device timing with external markings for easy identification. Unmatched Strength & Durability: Made from high-strength steel, equal to or stronger than barrel steel, ensuring failsafe strength. No Shear-Slip or Yielding: With its monolithic construction and significant thickness, AccuWasher shims resist deformation under heavy impact or bending loads. Maintains Accuracy & Safety: Eliminates alignment issues caused by traditional shims, preventing accuracy loss even under rough handling. Reliable for Suppressors & Muzzle Brakes: Provides the highest insurance against misalignment due to bumps, drops, or impacts. Fast, Intuitive Installation: External markings make it the easiest and most precise alignment system on the market. Note: The AccuWasher Alignment System can be used with any brand muzzle device.



Attributes

- Name: [PRECISION ARMAMENT ACCUWASHER AW750 GEN2 SHIM KIT - 1/2-28 .925"](#)
- Manufacturer: [PRECISION ARMAMENT](#)
- Product no.: 430113320
- Mfr. No.: A00503
- Colour: Stainless Steel
- Material: Stainless Steel
- Delivery weight: 0.041kg
- Shipping height: 127mm
- Shipping width: 76mm
- Shipping length: 25mm
- UPC: 810112081299

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [ACCUWASHER GEN 2 Muzzle Device Alignment System Safety Instructions](#)
- [About Us](#)

ACCUWASHER GEN 2 Muzzle Device Alignment System Safety Instructions

Introduction

Thank you for choosing the ACCUWASHER GEN 2 Muzzle Device Alignment System. This product is designed to enhance the accuracy and safety of your muzzle device alignment. Please read this safety instruction guide carefully to ensure proper usage and to minimize any potential risks.

General Safety Guidelines

- Always ensure that the ACCUWASHER GEN 2 is compatible with your specific muzzle device before installation.
- Inspect the product for any visible damage or defects before use.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose as described in this manual.
- In case of any malfunction or damage, discontinue use immediately and seek professional assistance.

Specific Safety Precautions for Use

- **Avoid Excessive Force:** When tightening the muzzle device, do not exceed the manufacturer's torque specifications to prevent damage to the device or the ACCUWASHER.
- **Check Alignment Regularly:** Ensure that the muzzle device remains properly aligned after installation, especially after any handling or transport.
- **Wear Protective Gear:** When working with firearms, always wear appropriate safety gear, including eye protection.
- **Use in a Controlled Environment:** Perform installation and adjustments in a safe and controlled environment away from unauthorized personnel.
- **Follow Local Laws:** Ensure compliance with all local laws and regulations regarding the use of firearms and muzzle devices.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including a torque wrench and any other required equipment.
- Ensure that the firearm is unloaded and in a safe condition before beginning installation.

2. Installation Steps:

- Clean the muzzle threads on the firearm to remove any debris or old thread sealant.
- Select the appropriate shim from the ACCUWASHER GEN 2 Shim Kit that corresponds to your muzzle device specifications.
- Place the shim onto the muzzle threads, ensuring it sits flat and is properly aligned.
- Carefully screw the muzzle device onto the shim, ensuring that it engages with the threads smoothly.
- Use the torque wrench to tighten the muzzle device to the manufacturer's specifications, ensuring not to overtighten.

3. PostInstallation Check:

- After installation, check the alignment of the muzzle device using the external markings on the shim for reference.

- Ensure that the device is secure and that there are no gaps between the device and the shim.

4. Usage:

- Regularly inspect the alignment and condition of the muzzle device during use.
- If any misalignment or damage is detected, stop using the firearm immediately and address the issue before further use.

Disposal Instructions

- Dispose of the ACCUWASHER GEN 2 and any shims in accordance with local regulations regarding metal waste.
- Do not dispose of the product in regular household waste. Instead, look for recycling programs or facilities that accept metal components.

Contact Information for Further Support

For any inquiries or concerns regarding the ACCUWASHER GEN 2 Muzzle Device Alignment System, please reach out to your retailer or the manufacturer directly for assistance.

Thank you for following these safety instructions. Your adherence to these guidelines helps ensure a safe and effective experience with the ACCUWASHER GEN 2 Muzzle Device Alignment System.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk