

ACCUWASHER GEN 2 MUZZLE DEVICE ALIGNMENT SYSTEM - PRECISION ARMAMENT ACCUWASHER AW625 GEN2 SHIM KIT - 5/8-24 .825"

[Rifle Parts](#) > [Barrel Parts](#) > [Rifle Barrel Hardware](#) > [Washers](#)

PRECISION ARMAMENT ACCUWASHER GEN 2 MUZZLE DEVICE ALIGNMENT SYSTEM The AccuWasher® Gen 2 Muzzle Device Alignment System is the ultimate solution for precise and repeatable muzzle device alignment. Unlike traditional crush washers, this mono-shim system is precision lathe-turned on both faces, ensuring a certified guaranteed circular thickness uniformity of .0001" for unparalleled accuracy. FEATURES: Precision Machined Mono-Shim: Provides exact muzzle device timing with external markings for easy identification. Unmatched Strength & Durability: Made from high-strength steel, equal to or stronger than barrel steel, ensuring failsafe strength. No Shear-Slip or Yielding: With its monolithic construction and significant thickness, AccuWasher shims resist deformation under heavy impact or bending loads. Maintains Accuracy & Safety: Eliminates alignment issues caused by traditional shims, preventing accuracy loss even under rough handling. Reliable for Suppressors & Muzzle Brakes: Provides the highest insurance against misalignment due to bumps, drops, or impacts. Fast, Intuitive Installation: External markings make it the easiest and most precise alignment system on the market. Note: The AccuWasher Alignment System can be used with any brand muzzle device.



Attributes

- Name: [PRECISION ARMAMENT ACCUWASHER AW625 GEN2 SHIM KIT - 5/8-24 .825"](#)
- Manufacturer: [PRECISION ARMAMENT](#)
- Product no.: 430113321
- Mfr. No.: A00520
- Colour: Stainless Steel
- Material: Stainless Steel
- Delivery weight: 0.041kg
- Shipping height: 127mm
- Shipping width: 76mm
- Shipping length: 25mm
- UPC: 810112081275

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [ACCUWASHER GEN 2 MUZZLE DEVICE ALIGNMENT SYSTEM SAFETY INSTRUCTIONS](#)
- [About Us](#)

ACCUWASHER GEN 2 MUZZLE DEVICE ALIGNMENT SYSTEM SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the ACCUWASHER GEN 2 Muzzle Device Alignment System. This product is designed to provide precise and repeatable alignment for muzzle devices, ensuring optimal performance and safety. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Always ensure that the ACCUWASHER GEN 2 is compatible with your specific muzzle device before installation.
- Inspect the product for any damage or defects before use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose as described in this guide.
- Report any unsafe products or accidents to the relevant authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Potential Hazards:**
 - Improper installation may lead to misalignment, affecting the performance and safety of your firearm.
 - The use of damaged or defective components can result in serious injury.
- **Avoiding Hazards:**
 - Always follow the installation instructions carefully.
 - Ensure that the product is securely fastened to prevent movement during use.
 - Do not exceed the recommended torque specifications during installation.
- **Audience Specific Warnings:**
 - This product is not intended for use by individuals under the age of 18 without adult supervision.
 - Ensure that all users are trained in the safe handling of firearms.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and ensure you have a clean workspace.
- Verify that your muzzle device is compatible with the ACCUWASHER GEN 2.

2. Installation Steps:

- Remove the existing muzzle device and any old washers.
- Clean the muzzle threads to ensure proper fit.
- Select the appropriate shim from the ACCUWASHER AW625 GEN2 Shim Kit.
- Align the shim on the muzzle threads, ensuring the external markings are visible for timing.
- Carefully screw the muzzle device onto the shim, ensuring it is aligned correctly.
- Tighten the muzzle device to the manufacturer's recommended torque specifications.

3. Usage:

- After installation, check for proper alignment by visually inspecting the muzzle device.
- Test the firearm in a safe environment to ensure that the alignment is correct and that there are

- no issues during operation.
- Regularly inspect the alignment and condition of the shim during routine maintenance.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Do not dispose of the product in household waste. Check for local recycling programs for metal products.
- Ensure that all components are disposed of safely to avoid potential hazards.

Contact Information for Further Support

For any questions or concerns regarding the ACCUWASHER GEN 2 Muzzle Device Alignment System, please refer to the manufacturer's website or contact their customer service for assistance.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and effective experience with your ACCUWASHER GEN 2 Muzzle Device Alignment System.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk