

CAM-LOCK® CASE TRIMMER PILOTS - CAM-LOCK CASE TRIMMER PILOT .375 CALIBER(0.375")

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmer Pilots](#)

CAM-LOCK CASE TRIMMER PILOTS Hornady® trimmer pilots are interchangeable in the Hornady Cam Lock Trimmer. SPECIFICATIONS:
Hardened Steel Available From .17 Caliber to .50 Caliber



Attributes

- Name: [CAM-LOCK CASE TRIMMER PILOT .375 CALIBER\(0.375"\)](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749000349
- Mfr. No.: 390958
- Caliber: 375 Caliber (.375)
- Delivery weight: 0.005kg
- Shipping height: 16mm
- Shipping width: 44mm
- Shipping length: 76mm
- UPC: 090255909586

Item details

Made in USA

Table of Contents

- Startpage
- CAMLOCK® CASE TRIMMER PILOTS Safety Instruction Guide
- About Us

CAMLOCK® CASE TRIMMER PILOTS Safety Instruction Guide

Introduction

Thank you for choosing the CAMLOCK® CASE TRIMMER PILOTS. This guide provides essential safety information to ensure the safe use and handling of your product. Please read it carefully before using the CAMLOCK CASE TRIMMER PILOT .375 CALIBER (0.375").

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as outlined in this guide.
- Keep the product out of reach of children and vulnerable individuals.
- Always inspect the product for any visible damage before use.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling the product.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use the CAMLOCK CASE TRIMMER PILOT with the Hornady Cam Lock Trimmer.
- Ensure that the trimmer is securely attached before operation to prevent accidents.
- Do not attempt to modify or alter the product in any way.
- Avoid wearing loose clothing or jewelry that may become entangled during use.
- Be cautious of sharp edges and moving parts while operating the trimmer.
- If you experience any discomfort or pain while using the product, stop immediately and consult a professional.

Instructions for Installation and Usage

1. Installation

- Remove the CAMLOCK CASE TRIMMER PILOT from its packaging.
- Ensure that the Hornady Cam Lock Trimmer is unplugged before installation.
- Insert the CAMLOCK CASE TRIMMER PILOT into the designated slot on the trimmer.
- Tighten the locking mechanism to secure the pilot in place.
- Doublecheck that the pilot is firmly attached before proceeding.

2. Usage

- Plug in the Hornady Cam Lock Trimmer and turn it on.
- Place the case to be trimmed securely in the trimmer.
- Gently feed the case into the pilot, ensuring it is aligned properly.
- Operate the trimmer according to the manufacturer's instructions.
- After trimming, turn off the trimmer and unplug it before removing the case and pilot.

Disposal Instructions

- Dispose of the CAMLOCK CASE TRIMMER PILOT in accordance with local regulations.
- Do not dispose of the product in household waste.
- Check with local waste management for proper disposal methods for metal products.

Contact Information for Further Support

For safety inquiries or further assistance regarding the CAMLOCK CASE TRIMMER PILOTS, please refer to the official Hornady website or contact their customer service directly.

Thank you for prioritizing safety while using the CAMLOCK CASE TRIMMER PILOTS. Your adherence to these guidelines helps ensure a safe and effective trimming experience.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz