

# **CAM-LOCK® CASE TRIMMER PILOTS - CAM-LOCK CASE TRIMMER PILOT .45 CALIBER(0.451")**

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmer Pilots](#)

CAM-LOCK CASE TRIMMER PILOTS Hornady® trimmer pilots are interchangeable in the Hornady Cam Lock Trimmer. SPECIFICATIONS: Hardened Steel Available From .17 Caliber to .50 Caliber



## **Attributes**

- Name: [CAM-LOCK CASE TRIMMER PILOT .45 CALIBER\(0.451"\)](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749000352
- Mfr. No.: 390961
- Caliber: 45 Caliber (.451-.454)
- Delivery weight: 0.023kg
- Shipping height: 5mm
- Shipping width: 58mm
- Shipping length: 76mm
- UPC: 090255909616

## **Item details**

Made in USA

# Table of Contents

- Startpage
- CAMLOCK® CASE TRIMMER PILOTS Safety Instruction Guide
- About Us

# CAMLOCK® CASE TRIMMER PILOTS Safety Instruction Guide

## Introduction

Thank you for choosing the CAMLOCK® CASE TRIMMER PILOTS, specifically designed for the Hornady® Cam Lock Trimmer. This guide provides essential safety instructions and guidelines to ensure safe and effective use of the product. Please read this guide carefully before use.

## General Safety Guidelines

- Ensure the product is used according to the manufacturer's specifications.
- Always inspect the product for any damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Wear appropriate safety gear, including eye protection, when operating the trimmer.
- Ensure the trimmer is securely mounted before use to prevent accidents.
- Do not exceed the recommended caliber specifications for the trimmer pilots.
- Avoid using the trimmer in wet or damp conditions.
- Do not modify or alter the product in any way.
- Always follow the manufacturer's guidelines for maintenance and storage.

## Instructions for Installation and Usage

### 1. Installation

- Ensure the Cam Lock Trimmer is turned off and unplugged.
- Select the appropriate CAMLOCK CASE TRIMMER PILOT for your caliber.
- Insert the pilot into the trimmer according to the manufacturer's instructions.
- Secure the pilot firmly in place to prevent it from loosening during use.

### 2. Usage

- Turn on the Cam Lock Trimmer and allow it to reach full speed before introducing the case.
- Gently insert the case into the trimmer, ensuring it is properly aligned with the pilot.
- Hold the case firmly but do not apply excessive force.
- Once trimming is complete, turn off the trimmer and carefully remove the case.
- Clean the trimmer and pilot after each use to maintain optimal performance.

## Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in general household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

## **Contact Information for Further Support**

For any inquiries regarding product safety or to report an unsafe product, please consult the appropriate EUbased contact point.

Thank you for prioritizing safety and for using the CAMLOCK® CASE TRIMMER PILOTS responsibly.

# About Us

## **Brownells Česká republika**

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.cz](http://www.brownells.cz)