

CAM-LOCK® CASE TRIMMER PILOTS - CAM-LOCK CASE TRIMMER PILOT .25 CALIBER(0.251")

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmer Pilots](#)

CAM-LOCK CASE TRIMMER PILOTS Hornady® trimmer pilots are interchangeable in the Hornady Cam Lock Trimmer. SPECIFICATIONS:
Hardened Steel Available From .17 Caliber to .50 Caliber



Attributes

- Name: [CAM-LOCK CASE TRIMMER PILOT .25 CALIBER\(0.251"\)](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749000367
- Mfr. No.: 390946
- Caliber: 25 Caliber (.257)
- Delivery weight: 0.023kg
- Shipping height: 15mm
- Shipping width: 43mm
- Shipping length: 81mm
- UPC: 090255909463

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [CAMLOCK® Case Trimmer Pilots Safety Instruction Guide](#)
- [About Us](#)

CAMLOCK® Case Trimmer Pilots Safety Instruction Guide

Introduction

Thank you for choosing the CAMLOCK® CASE TRIMMER PILOTS. This product is designed for use with the Hornady® Cam Lock Trimmer and is suitable for trimming cases of .25 caliber (0.251"). To ensure safe and effective use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product before each use for any signs of damage or wear.
- Do not use the product if it appears damaged or malfunctioning.
- Store the product in a dry and secure location when not in use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the trimmer is securely mounted before use to prevent accidents.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, while operating the trimmer.
- Never place your hands near the cutting area during operation.
- Keep the workspace clear of any unnecessary tools or materials to avoid distractions.
- Use only compatible trimmer pilots with the Hornady® Cam Lock Trimmer to prevent malfunctions.
- Avoid using the product near flammable materials or liquids.

Instructions for Installation and Usage

1. Installation of the Trimmer Pilot:

- Ensure the Hornady® Cam Lock Trimmer is unplugged and not in operation.
- Select the appropriate CAMLOCK® case trimmer pilot for your caliber.
- Carefully insert the pilot into the trimmer's collet and tighten securely.
- Doublecheck that the pilot is properly installed before proceeding.

2. Using the Trimmer:

- Place the case securely in the trimmer.
- Adjust the trimmer settings according to the desired case length.
- Turn on the trimmer and allow it to reach the necessary speed before feeding the case.
- Feed the case into the pilot gently, without forcing it.
- Once the trimming is complete, turn off the trimmer and remove the finished case.

3. PostUse Care:

- Clean the trimmer and pilot after each use to remove debris and prevent rust.
- Store the trimmer and pilots in their designated storage area to avoid damage.

Disposal Instructions

- Dispose of packaging materials in accordance with local waste management regulations.
- If the product is no longer in use or is damaged beyond repair, follow local guidelines for disposing of metal and plastic components.
- Do not dispose of the product in household waste if it is deemed hazardous.

Contact Information for Further Support

For any questions regarding safety or product support, please consult the manufacturer's website or customer service for assistance. Ensure you have the product details on hand for a quicker response.

Thank you for your attention to these safety instructions. Your safety is our priority.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz