

AUTO PRIME SHELLHOLDERS - LEE AUTO PRIME SHELLHOLDER #6

[Reloading](#) > [Shellholders & Shellplates](#)

Lee Universal Shell Holders function in the Lee handheld priming tools. Machined to close tolerances for maximum accuracy. Manufactured from hardened steel. View Lee Shellholder Chart



Attributes

- Name: [LEE AUTO PRIME SHELLHOLDER #6](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 749000382
- Mfr. No.: 90206
- Cartridge: 218 Bee, 25-20 Winchester, 32-20 Winchester
- Style: Priming Tool
- Delivery weight: 0.032kg
- Shipping height: 1mm
- Shipping width: 97mm
- Shipping length: 127mm
- UPC: 734307902063

Item details

Made in USA

Table of Contents

- Startpage
- AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #6 Safety Instructions
- About Us

AUTO PRIME SHELLHOLDERS LEE AUTO PRIME SHELLHOLDER #6 Safety Instructions

Introduction

Thank you for choosing the Lee Auto Prime Shellholder #6. This product is designed for use with Lee handheld priming tools and is manufactured to ensure maximum accuracy and safety. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always read the product manual before use.
- Ensure that the shellholder is compatible with your specific priming tool and cartridges.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the shellholder for any signs of damage or wear before each use.
- Use the product only for its intended purpose, as specified by the manufacturer.
- Do not modify or alter the shellholder in any way.
- Follow all local laws and regulations regarding the use of reloading equipment and components.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), such as safety glasses, when using the shellholder.
- Avoid wearing loose clothing or jewelry that may get caught in the reloading equipment.
- Ensure your workspace is clean and free of clutter to prevent accidents.
- Do not use the shellholder if you are tired or under the influence of substances that may impair your judgment.
- Always handle reloading components with care, and store them in a safe, dry place.

Instructions for Installation and Usage

1. Installation:

- Ensure your Lee handheld priming tool is clean and free of debris.
- Align the shellholder with the priming tool, ensuring it fits securely.
- Twist or push the shellholder into place until it is firmly seated.

2. Usage:

- Select the appropriate cartridge for the shellholder (compatible cartridges include 218 Bee, 2520 Winchester, and 3220 Winchester).
- Load the priming tool with the shellholder installed.
- Follow the manufacturer's instructions for priming cartridges, ensuring proper technique is used.
- After use, remove the shellholder from the priming tool and clean it as necessary.

Disposal Instructions

- Dispose of the shellholder in accordance with local regulations for metal products.
- Do not dispose of the shellholder in regular household waste.
- If the shellholder is damaged or no longer usable, consider recycling it if possible.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Lee Auto Prime Shellholder #6, please contact the manufacturer or your local retailer for assistance. Always ensure you have the product details on hand when seeking support.

Thank you for prioritizing safety in your reloading practices. Enjoy using your Lee Auto Prime Shellholder #6 responsibly!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at