

MEC POWDER BUSHINGS - #36 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [#36 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749010736
- Mfr. No.: 5036
- Size: #36
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 098489016292

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings #36 Safety Instruction Guide
- About Us

MEC Powder Bushings #36 Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushings #36. This guide provides important safety information and instructions to ensure the safe and effective use of this product. Please read and follow these guidelines carefully.

General Safety Guidelines

- Always use the MEC Powder Bushings in accordance with the manufacturer's instructions.
- Ensure that the workspace is clean, dry, and free from distractions while loading powder.
- Keep the powder bushings out of reach of children and pets.
- Use a scale to check powder weights for accuracy.
- Regularly inspect the bushings for damage or wear before each use.
- In case of any accidents or unsafe conditions, report them to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that you are using the correct bushing size for your specific powder load.
- Do not exceed the recommended powder load as indicated by the powder charts.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and a dust mask, when handling powders.
- Avoid inhaling powder dust or fumes.
- Do not eat, drink, or smoke while handling powder or using the bushings.
- In case of skin contact with powder, wash the affected area thoroughly with soap and water.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Select the appropriate MEC powder bushing size for your desired powder load.
- Insert the bushing into the designated slot on the reloading press, ensuring a snug fit.
- Check that the bushing is properly seated before proceeding.

2. Usage:

- Before starting, verify that the reloading press is empty and clean.
- Set the scale to zero and place the container for the powder on the scale.
- Pull the handle of the reloading press to dispense the powder through the bushing.
- Weigh the dispensed powder and adjust the bushing as necessary to achieve the desired weight.
- Repeat the process until the correct powder load is achieved.

Disposal Instructions

- Dispose of any unused or excess powder according to local regulations.
- Recycle the packaging materials whenever possible.
- Do not dispose of powder in regular household waste or down the drain.

Contact Information for Further Support

For any questions or concerns regarding the MEC Powder Bushings #36, please refer to the MEC website or contact the appropriate customer support channels.

Thank you for your attention to these safety guidelines. Your safety is our priority.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at