

# MEC LEAD CHARGE BARS FOR SINGLE STAGE PRESS - MEC RELOADING 11/16OZ SINGLE STAGE LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses.



## Attributes

- Name: [MEC RELOADING 11/16OZ SINGLE STAGE LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019402
- Mfr. No.: 3021116
- Size: 11/16 oz
- Delivery weight: 0.249kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489013871

## Item details

Made in USA

# Table of Contents

- Startpage
- MEC Lead Charge Bars Safety Instruction Guide
- About Us

# MEC Lead Charge Bars Safety Instruction Guide

## Introduction

Thank you for choosing the MEC Lead Charge Bars for your reloading needs. This guide provides essential safety instructions to ensure the safe use of the product. Please read this document carefully before using the MEC Charge Bars.

## General Safety Guidelines

- Ensure that the MEC Charge Bars are used only with compatible MEC reloading presses.
- Always follow the manufacturer's instructions for your specific reloading press model.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Charge Bars for any signs of wear or damage before use.
- If you notice any defects or issues, discontinue use immediately and contact the manufacturer for guidance.
- Report any unsafe product experiences or accidents to the relevant authorities.

## Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when handling lead materials.
- Avoid inhaling dust or fumes generated during the reloading process.
- Ensure that your workspace is wellventilated.
- Do not exceed the recommended charge weight specified for the Charge Bars.
- Store the Charge Bars in a cool, dry place away from direct sunlight and moisture.
- Follow local regulations regarding the handling and disposal of lead materials.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure your reloading press is turned off and unplugged before beginning installation.
- Remove the existing charge bar from the press by following the manufacturer's instructions.
- Insert the MEC Lead Charge Bar into the designated slot, ensuring it is securely locked in place.
- Reattach any components that were removed during installation.

### 2. Usage:

- Adjust the shot charge according to your desired load specifications.
- Carefully measure the lead shot to avoid overloading the charge bar.
- Operate the reloading press according to the manufacturer's guidelines.
- After reloading, clean the Charge Bar to remove any residue or buildup.

## Disposal Instructions

- Dispose of any lead materials in accordance with local regulations and guidelines.
- Do not dispose of lead in regular household waste.
- Contact local waste management authorities for information on safe disposal methods for lead products.

## Contact Information for Further Support

For further assistance, please refer to the manufacturer's website or contact their customer service team. They can provide additional safety information and support regarding the MEC Lead Charge Bars.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and effective reloading experience with your MEC Charge Bars.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)