

MEC LEAD CHARGE BARS FOR SINGLE STAGE PRESS - MEC RELOADING 1-3/8OZ SINGLE STAGE LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses.



Attributes

- Name: [MEC RELOADING 1-3/8OZ SINGLE STAGE LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019407
- Mfr. No.: 302138
- Size: 1-3/8 oz
- Delivery weight: 0.243kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489011174

Item details

Made in USA

Table of Contents

- Startpage
- MEC Lead Charge Bars for Single Stage Press Safety Instruction Guide
- About Us

MEC Lead Charge Bars for Single Stage Press Safety Instruction Guide

Introduction

Thank you for choosing the MEC Lead Charge Bars for your single stage reloading needs. This guide provides essential safety instructions to ensure the safe use of the product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always follow the manufacturer's instructions when using the charge bars.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the charge bars for any signs of wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when reloading.
- Do not exceed the recommended shot charge for your reloading press.
- Ensure that the charge bar is securely attached before use.
- Avoid using the charge bars in wet or humid conditions.
- Do not attempt to modify the charge bars in any way.
- Store the charge bars in a cool, dry place when not in use.

Instructions for Installation and Usage

1. Installation:

- Remove the existing charge bar from your reloading press.
- Align the MEC Lead Charge Bar with the mounting point on the press.
- Securely attach the charge bar using the provided hardware, ensuring it is tight and stable.
- Doublecheck that the charge bar is properly installed before proceeding.

2. Usage:

- Adjust the charge bar to the desired shot charge setting.
- Ensure the reloading press is empty before starting the loading process.
- Load the appropriate amount of lead or steel shot into the charge bar.
- Operate the reloading press according to the manufacturer's instructions.
- Monitor the loading process to ensure consistent performance.

Disposal Instructions

- Dispose of any damaged or worn charge bars in accordance with local waste disposal regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please refer to the manufacturer's contact information provided with the product packaging.

Thank you for prioritizing safety while using the MEC Lead Charge Bars. Your adherence to these guidelines ensures a safe and effective reloading experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk