

MEC LEAD CHARGE BARS FOR SINGLE STAGE PRESS - MEC RELOADING 5/8OZ SINGLE STAGE LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses.



Attributes

- Name: [MEC RELOADING 5/8OZ SINGLE STAGE LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019413
- Mfr. No.: 30258
- Size: 5/8 oz
- Delivery weight: 0.249kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489014823

Item details

Made in USA

Table of Contents

- Startpage
- MEC Lead Charge Bars Safety Instructions
- About Us

MEC Lead Charge Bars Safety Instructions

Introduction

Thank you for choosing the MEC Lead Charge Bars for your reloading needs. These charge bars are designed to help you adjust your shot charge and create the load you desire. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always follow the manufacturer's instructions for safe use.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling lead materials.
- Ensure that your reloading press is stable and securely positioned before installation.
- Avoid inhaling dust or fumes that may be generated during the reloading process.
- Store lead charge bars in a dry, cool place away from direct sunlight to prevent degradation.
- Do not exceed the maximum load capacity specified for your reloading press.

Instructions for Installation and Usage

1. Installation

- Ensure your reloading press is turned off and unplugged.
- Remove the existing charge bar from the press by following the manufacturer's instructions.
- Align the MEC Lead Charge Bar with the press's mounting points.
- Secure the charge bar in place according to the manufacturer's guidelines.

2. Usage

- Adjust the charge bar to the desired shot weight (5/8 oz) by following the manufacturer's instructions.
- Load the appropriate materials into the press, ensuring they are compatible with the charge bar.
- Perform a test run to verify that the charge bar dispenses the correct amount of shot.
- Monitor the reloading process closely to ensure consistent and safe operation.

Disposal Instructions

- Dispose of any unused or damaged charge bars in accordance with local regulations regarding hazardous materials.
- Do not dispose of lead materials in regular waste. Check for local recycling programs that accept lead.
- If in doubt, contact local waste management authorities for guidance on safe disposal.

Contact Information for Further Support

For any questions or concerns regarding the MEC Lead Charge Bars, please refer to the manufacturer's contact

details provided with your product packaging. It is important to reach out to them for support and to ensure compliance with safety regulations.

Thank you for prioritizing safety while using the MEC Lead Charge Bars. Your commitment to safe reloading practices helps ensure a secure environment for all users.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk