

MEC LEAD CHARGE BAR PROGRESSIVE PRESS - MEC RELOADING 11/16OZ LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses. Steel shot bars are available by special order.



Attributes

- Name: [MEC RELOADING 11/16OZ LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019414
- Mfr. No.: 5021116
- Size: 11/16 oz
- Delivery weight: 0.245kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489013017

Item details

Made in USA

Table of Contents

- Startpage
- MEC Lead Charge Bar Progressive Press Safety Instruction Guide
- About Us

MEC Lead Charge Bar Progressive Press Safety Instruction Guide

Introduction

Thank you for choosing the MEC Lead Charge Bar for your reloading needs. This guide provides essential safety instructions to ensure the safe and effective use of the product. By following these guidelines, you can minimize risks and enjoy a safe reloading experience.

General Safety Guidelines

- Always read and understand the product manual before use.
- Ensure that the reloading area is wellventilated and free from distractions.
- Keep the reloading equipment out of reach of children and pets.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling materials.
- Regularly inspect the MEC Lead Charge Bar for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the charge bar is properly installed on the reloading press before use.
- Do not exceed the recommended shot charge capacity of 11/16 oz.
- Always use the appropriate type of shot (lead or steel) as specified for your reloading press.
- Avoid using the charge bar in wet or damp conditions to prevent corrosion and malfunction.
- Do not attempt to modify the charge bar or any related components.
- Keep fingers and hands clear of moving parts during operation to prevent injury.
- Follow all local regulations regarding the use of lead and steel shot.

Instructions for Installation and Usage

1. Installation

- Disconnect the reloading press from any power source.
- Remove the existing charge bar from the reloading press by following the manufacturer's instructions.
- Align the MEC Lead Charge Bar with the mounting points on the reloading press.
- Securely attach the charge bar, ensuring it is fitted correctly and tightly.
- Reconnect the reloading press to the power source.

2. Usage

- Set the desired shot charge by adjusting the MEC Lead Charge Bar according to the load you want to create.
- Always doublecheck the shot charge setting before starting the reloading process.
- Begin reloading by following the standard operating procedures for your reloading press.
- Monitor the reloading process closely for any irregularities or issues.

Disposal Instructions

- Dispose of any unused or expired materials in accordance with local regulations.
- Do not throw away the MEC Lead Charge Bar in regular trash if it is damaged. Instead, follow local hazardous waste disposal guidelines.
- If you are unsure about disposal methods, consult with local waste management authorities for proper

procedures.

Contact Information for Further Support

For safety inquiries or additional support regarding the MEC Lead Charge Bar, please reach out to the designated EU contact point provided by the manufacturer. This ensures you receive accurate and timely information regarding product safety and usage.

Thank you for your attention to these safety instructions. By adhering to these guidelines, you can ensure a safe and enjoyable reloading experience with the MEC Lead Charge Bar.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk