

MEC LEAD CHARGE BAR PROGRESSIVE PRESS - MEC RELOADING 1-1/4OZ LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses. Steel shot bars are available by special order.



Attributes

- Name: [MEC RELOADING 1-1/4OZ LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019416
- Mfr. No.: 502114
- Size: 1-1/4 oz
- Delivery weight: 0.239kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489013864

Item details

Made in USA

Table of Contents

- Startpage
- MEC Lead Charge Bar Safety Instruction Guide
- About Us

MEC Lead Charge Bar Safety Instruction Guide

Introduction

Thank you for choosing the MEC Lead Charge Bar Progressive Press. This product is designed to help you adjust your shot charge and create the load you desire for reloading. To ensure safe and effective usage, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always ensure that the MEC Lead Charge Bar is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the charge bar for any signs of wear or damage before use.
- Avoid using the charge bar if it is damaged or malfunctioning.
- Store the charge bar in a dry and secure location when not in use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the reloading press is properly secured before attaching or adjusting the charge bar.
- Use only the recommended lead or steel shot for your specific charge bar model.
- Do not exceed the maximum load capacity specified for the charge bar.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, while reloading.
- Do not attempt to modify the charge bar or use it for any purpose other than its intended use.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged.
- Remove the existing charge bar from the reloading press if applicable.
- Align the MEC Lead Charge Bar with the mounting brackets on the press.
- Securely fasten the charge bar in place according to the manufacturer's instructions.
- Doublecheck that the charge bar is properly installed and stable before proceeding.

2. Usage

- Measure the desired shot charge using the markings on the charge bar.
- Fill the charge bar with the appropriate lead or steel shot.
- Operate the reloading press according to the manufacturer's guidelines.
- Monitor the reloading process to ensure consistent and safe operation.
- After use, clean the charge bar to remove any residue or debris.

Disposal Instructions

- Dispose of any broken or damaged parts of the charge bar in accordance with local regulations.
- Recycle materials where possible, following your local waste management guidelines.
- Do not dispose of the charge bar in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's contact information provided

with your product. It is important to seek help if you have any concerns regarding the safety or functionality of the MEC Lead Charge Bar.

By following these safety instructions, you can ensure a safe and effective reloading experience with your MEC Lead Charge Bar. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk