

SCREW TRIGGER PLATE 486 12GA - BERETTA USA SCREW TRIGGER PLATE 486 12GA

[Shotgun Parts](#) > [Trigger Group Parts](#) > [Trigger Plate Parts](#) > [Trigger Plate Screws](#)

FITS: 486, 12ga

SCREW TRIGGER PLATE 486 12GA

NO IMAGE
AVAILABLE

Attributes

- Name: [BERETTA USA SCREW TRIGGER PLATE 486 12GA](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913000623
- Mfr. No.: C5E052
- Model: 486
- Weapon type: Beretta
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 3mm
- Shipping length: 5mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for SCREW TRIGGER PLATE 486 12GA](#)
- [About Us](#)

Safety Instruction Guide for SCREW TRIGGER PLATE 486 12GA

Introduction

Thank you for choosing the SCREW TRIGGER PLATE 486 12GA by Beretta USA. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of this product. It complies with the EU General Product Safety Regulation (GPSR) to protect consumers and promote safe usage.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified by the manufacturer.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear before use.
- Follow all instructions carefully to avoid accidents or injuries.
- In case of any doubts or questions regarding the product, seek professional advice.

Specific Safety Precautions for Use

- Always wear appropriate safety gear (e.g., gloves, goggles) when handling the screw trigger plate.
- Ensure that the firearm is unloaded before installing or replacing the trigger plate.
- Avoid using excessive force during installation to prevent damage to the product or the firearm.
- Do not modify the product in any way, as this may compromise safety and functionality.
- If you notice any unusual behavior or malfunction during use, stop using the product immediately and seek assistance.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is completely unloaded and safe to handle.
- Gather all necessary tools for installation.

2. Installation Steps

- Locate the trigger plate area on the firearm.
- Align the screw trigger plate with the designated mounting points.
- Carefully insert the screws into the predrilled holes.
- Use a screwdriver to tighten the screws, ensuring they are secure but not overtightened.

3. PostInstallation Check

- Verify that the trigger plate is securely attached and functioning correctly.
- Test the firearm in a safe environment to ensure proper operation.

4. Usage

- Always follow safe firearm handling practices.
- Store the firearm in a secure location when not in use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.

- Do not dispose of the product in household waste.
- Check for any specific disposal guidelines provided by local authorities or waste management facilities.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the SCREW TRIGGER PLATE 486 12GA, please refer to your local Beretta USA contact point or authorized dealer.

Conclusion

By adhering to these safety instructions and guidelines, you can ensure the safe use of the SCREW TRIGGER PLATE 486 12GA. Always prioritize safety and seek assistance when needed. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk