

SEAR - BERETTA USA AL 391 XTREME SEAR

[Shotgun Parts](#) > [Trigger Group Parts](#) > [Sear Parts](#) > [Sears](#)

FITS: A391-Xtrema, 12

SEAR



Attributes

- Name: [BERETTA USA AL 391 XTREME SEAR](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913200323
- Mfr. No.: C59926
- Model: AL391 Xtrema
- Weapon type: Beretta
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

US export classification: 0A501.c

Table of Contents

- [Startpage](#)
- [SEAR BERETTA USA AL 391 XTREME SEAR Safety Instruction Guide](#)
- [About Us](#)

SEAR BERETTA USA AL 391 XTREME SEAR Safety Instruction Guide

Introduction

Thank you for choosing the SEAR BERETTA USA AL 391 XTREME SEAR. This guide provides important safety instructions to ensure the safe use of this product. Please read this document carefully before using the sear, and keep it for future reference.

General Safety Guidelines

- Ensure that you are familiar with the operation and maintenance of your firearm before using this sear.
- Always follow the manufacturer's instructions and guidelines for your firearm.
- Store the sear and any related components in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the sear for any signs of wear or damage. If you notice any issues, do not use the sear and contact a qualified gunsmith.
- Be aware of your surroundings when handling firearms to prevent accidents and ensure safety for yourself and others.

Specific Safety Precautions for Use

- Only use the SEAR BERETTA USA AL 391 XTREME SEAR with compatible Beretta firearms.
- Never attempt to modify or alter the sear or any of its components. Modifications can lead to unsafe conditions and malfunctions.
- Always ensure that the firearm is unloaded before installing or removing the sear.
- Use appropriate personal protective equipment (PPE) such as safety glasses when handling firearms.
- Be cautious of any potential hazards, including but not limited to:
 - Misfires
 - Accidental discharges
 - Mechanical failures

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools as per the manufacturer's specifications.

2. Installation:

- Remove the existing sear from the firearm following the manufacturer's guidelines.
- Carefully install the SEAR BERETTA USA AL 391 XTREME SEAR into the firearm, ensuring it is seated correctly.
- Doublecheck the installation to confirm that the sear is securely in place.

3. Testing:

- After installation, conduct a function test to ensure the sear operates correctly.
- Follow the specific testing procedures outlined in your firearm's manual.

4. Usage:

- Use the firearm according to the manufacturer's instructions.
- Always handle the firearm with care and respect, treating it as if it is loaded.

Disposal Instructions

- Dispose of any damaged or worn sears in accordance with local regulations.
- Do not throw away the sear in regular trash. Instead, contact local authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further information regarding the SEAR BERETTA USA AL 391 XTREME SEAR, please consult the manufacturer's official website or contact an authorized dealer.

Conclusion

By following these safety instructions, you can help ensure the safe operation of the SEAR BERETTA USA AL 391 XTREME SEAR. Always prioritize safety and remain informed about best practices when handling firearms. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk