

SPRING, COCKING LEVER 680 - BERETTA USA SPRING, COCKING LEVER 680

[Shotgun Parts](#) > [Bolt Parts](#) > [Cocking Parts](#) > [Cocking Springs](#)

FITS: 690 Field III, 12 Ga; 692 Trap, 12; S682, 12, 20

SPRING, COCKING LEVER 680

Spring, Cocking Lever 680



Attributes

- Name: [BERETTA USA SPRING, COCKING LEVER 680](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913300451
- Mfr. No.: C90225
- Model: S682,692 Trap
- Weapon type: Beretta
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Table of Contents

- [Startpage](#)
- [SPRING, COCKING LEVER 680 User Safety Instructions](#)
- [About Us](#)

SPRING, COCKING LEVER 680 User Safety Instructions

Introduction

Thank you for choosing the SPRING, COCKING LEVER 680 by Beretta USA. This guide provides essential safety instructions to ensure the safe use of this product. Please read this manual carefully before use to understand the safety precautions and proper handling of the cocking lever spring.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as outlined in this manual.
- Always keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- If you notice any defects or malfunctions, discontinue use immediately and seek assistance.
- Follow all local laws and regulations regarding the use of firearms and related components.

Specific Safety Precautions for Use

- Only use the SPRING, COCKING LEVER 680 with compatible Beretta models, specifically S682 and S692 Trap.
- Avoid using excessive force when handling the cocking lever spring to prevent injury or damage.
- Wear appropriate personal protective equipment (PPE) such as safety glasses when handling the product.
- Do not modify or alter the product in any way, as this may lead to unsafe conditions.
- Ensure that the firearm is unloaded and pointed in a safe direction when installing or adjusting the cocking lever spring.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is unloaded.
- Gather all necessary tools for installation.

2. Installation:

- Locate the cocking lever assembly on your Beretta firearm.
- Carefully remove the old cocking lever spring if applicable.
- Insert the SPRING, COCKING LEVER 680 into the designated area, ensuring it is properly seated.
- Reassemble the cocking lever assembly according to the manufacturer's instructions.

3. Usage:

- After installation, test the cocking lever to ensure it operates smoothly.
- Regularly check the operation of the cocking lever spring during routine firearm maintenance.

Disposal Instructions

- Dispose of the SPRING, COCKING LEVER 680 in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For any questions or concerns regarding the SPRING, COCKING LEVER 680, please reach out to your local Beretta dealer or authorized service center. Ensure you have the product information ready for a more efficient support experience.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the SPRING, COCKING LEVER 680. Always prioritize safety and comply with local regulations when handling firearms and their components. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk