

# Shotgun Chamber Flag - This is my safety!

[Shooting Accessories](#) > [Training & Safety Gear](#) > [Chamber Safety Flags](#)

Bright Neon green chamber flags to easily identify an unloaded firearm.

NO IMAGE  
AVAILABLE

## Attributes

- Name: [Shotgun Chamber Flag - This is my safety!](#)
- Manufacturer: [Brownells Europe](#)
- Product no.: EU2011999
- Mfr. No.: EU2011999
- Colour: Neon Green
- Delivery weight: 0.1kg

# Table of Contents

- [Startpage](#)
- [Shotgun Chamber Flag Safety Instructions](#)
- [About Us](#)

# Shotgun Chamber Flag Safety Instructions

## Introduction

Thank you for choosing the Shotgun Chamber Flag. This bright neon green chamber flag is designed to help you easily identify an unloaded firearm, enhancing safety during storage and handling. This safety instruction guide is compliant with the EU General Product Safety Regulation (GPSR) to ensure your safety and the safety of others.

## General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Use the chamber flag to indicate that the firearm is unloaded.
- Store firearms safely and securely, away from unauthorized access, especially by children.
- Regularly inspect the chamber flag for any signs of wear or damage.
- Keep the chamber flag clean and free from obstructions.
- Report any unsafe products or incidents to the relevant authorities immediately.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Ensure the firearm is completely unloaded before inserting the chamber flag.
- Do not rely solely on the chamber flag as a safety device; always follow safe handling practices.
- Avoid using the chamber flag in firearms that are not designed to accommodate it.
- Keep the chamber flag out of reach of children and pets when not in use.
- Do not modify or alter the chamber flag in any way.

## Instructions for Installation and Usage

### 1. Inserting the Chamber Flag:

- Open the action of the firearm to ensure it is unloaded.
- Insert the chamber flag into the chamber of the firearm until it is fully seated.
- Close the action of the firearm, ensuring that the chamber flag remains visible.

### 2. Removing the Chamber Flag:

- Open the action of the firearm.
- Carefully remove the chamber flag from the chamber.
- Store the chamber flag in a safe location when not in use.

### 3. Regular Checks:

- Periodically inspect the chamber flag for any damage or wear.
- Replace the chamber flag if it shows any signs of deterioration.

## Disposal Instructions

- Dispose of the chamber flag in accordance with local regulations.
- Do not dispose of the chamber flag in regular household waste if it shows signs of damage.
- Consider recycling options if available.

## **Contact Information for Further Support**

For safety inquiries or further support regarding the Shotgun Chamber Flag, please refer to your local retailer or the manufacturer's website for contact details.

By following these safety instructions and guidelines, you can ensure a safer experience while using your Shotgun Chamber Flag. Your safety and the safety of those around you is our priority. Thank you for your attention to these important safety measures.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)