

## NO. 3 1.75X MAGNIFICATION OPTICAL GLASS

[Gunsmith Tools](#) > [General Gunsmith Tools](#) > [Visors & Magnifiers](#)

### Continuous Headband; Dial Adjustable

DIAL ADJUSTABLE CONTINUOUS HEADBAND - Specially formed to fit. A simple twist of the adjusting dial changes head size. Sealed-in mechanism is self-locking and trouble-free. Gives better balance and even more comfort. IT TILTS - Adjustable pivots make the OptiVISOR unique - and the most handy magnifier yet. It's up, out of the way of normal vision when not in use, and there at your fingertips when you need it for magnified pinpoint clarity back at the job. CONFORMING HEADBAND - Of electrically nonconductive ABS material. Designed to fit and locate the scope in a natural, comfortable position. Total weight just 4 oz. So light you hardly know it's there. GENUINE LEATHER COMFORT BAND - Padded with orthopedic felt, making the OptiVISOR the most comfortably worn magnifier available. ABS HI-IMPACT VISOR - This tough, durable material is practically indestructible, yet always keeps its new appearance. OPTICAL GLASS LENSES - Ground and polished to precision optical standards. Beveled edges and mounted in interchangeable plastic frames. Five scientifically computed prismatic powers are available for use with any OptiVISOR FITS OVER REGULAR GLASSES - No need to take them off with the OptiVISOR.



### Attributes

- Name: [OPTIVISOR NO. 3 1.75X MAGNIFICATION OPTICAL GLASS](#)
- Manufacturer: [OPTIVISOR](#)
- Product no.: 255003000
- Mfr. No.: DA-3
- Delivery weight: 0.204kg
- Shipping height: 56mm
- Shipping width: 206mm
- Shipping length: 257mm
- UPC: 633096000489

### Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [OPTIVISOR No. 3 Safety Instruction Guide](#)
- [About Us](#)

# OPTIVISOR No. 3 Safety Instruction Guide

## Introduction

Thank you for choosing the OPTIVISOR No. 3 with 1.75X magnification optical glass. This guide provides essential safety instructions and recommendations to ensure safe and effective use of your magnifier. Please read this guide carefully before using the product.

## General Safety Guidelines

- Always use the OPTIVISOR as intended to avoid accidents or injuries.
- Ensure that the magnifier is in good condition before each use. Inspect for any cracks or damage.
- Keep the OPTIVISOR out of reach of children to prevent misuse or accidents.
- If you experience discomfort or vision problems while using the OPTIVISOR, discontinue use immediately and consult a professional.
- Follow all local regulations regarding the use and disposal of optical products.

## Specific Safety Precautions for Use

- **Headband Adjustment:** Always adjust the headband to fit comfortably and securely before use. A loose headband may cause the magnifier to slip or fall.
- **Avoid Direct Sunlight:** Do not use the OPTIVISOR in direct sunlight for extended periods, as this may cause overheating or discomfort.
- **Cleaning Lenses:** Use a soft, lintfree cloth to clean the optical glass lenses. Avoid using harsh chemicals or abrasive materials that may scratch the lenses.
- **Wearing Glasses:** If you wear prescription glasses, ensure that they fit comfortably under the OPTIVISOR. The device is designed to fit over regular glasses.
- **Storage:** Store the OPTIVISOR in a dry place when not in use. Avoid exposing it to extreme temperatures or humidity.

## Instructions for Installation and Usage

### 1. Adjusting the Headband:

- Locate the adjusting dial on the headband.
- Twist the dial to increase or decrease the size of the headband, ensuring a snug fit on your head.
- Test the fit by gently shaking your head; the magnifier should remain securely in place.

### 2. Using the Magnifier:

- Position the OPTIVISOR comfortably on your head, ensuring the optical glass lenses are aligned with your eyes.
- Tilt the magnifier down when you need to use it, and tilt it up when you need your normal vision.
- Adjust the angle of the visor using the adjustable pivots for optimal viewing comfort.

### 3. Cleaning the Lenses:

- Use a soft, dry cloth to wipe the lenses before and after each use.
- If necessary, dampen the cloth slightly with water for more thorough cleaning, but ensure the lenses are dry before storing.

### 4. Replacing Lenses:

- If you need to change the magnification lenses, carefully remove the old lenses from the plastic

frames.

- Insert the new lenses into the frames, ensuring they are seated properly and securely.

## **Disposal Instructions**

- Dispose of the OPTIVISOR according to local waste management regulations.
- Do not dispose of the product in regular household waste. Instead, check for recycling programs that accept optical products.
- If the product is damaged beyond repair, ensure that it is disposed of safely to prevent any potential hazards.

## **Contact Information for Further Support**

For any questions or concerns regarding the OPTIVISOR, please refer to the manufacturer's website or customer service resources for assistance.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)