

MEC POWDER BUSHINGS - #17 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [#17 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749009396
- Mfr. No.: 5017
- Size: #17
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 098489016926

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings #17 Safety Instruction Guide
- About Us

MEC Powder Bushings #17 Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushings #17. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read this guide carefully before installation and usage.

General Safety Guidelines

- Ensure the product is used in accordance with the manufacturer's instructions.
- Always handle powder bushings with care to avoid accidental spills or exposure to powder.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product in a wellventilated area to minimize inhalation risks.
- Regularly check for any signs of wear or damage to the bushing before use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Always use a scale to verify powder weights for accuracy.
- Do not exceed the recommended powder load for your rounds.
- Avoid using the bushing if it appears damaged or worn.
- Wear appropriate protective gear, such as safety glasses and gloves, when handling powders.
- Do not mix different types of powders in the same bushing.
- Store powder bushings in a cool, dry place away from direct sunlight and moisture.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Locate the appropriate slot for the bushing on your reloading press.
- Insert the MEC Powder Bushing #17 securely into the designated slot.
- Ensure it is properly seated and locked in place.

2. Usage:

- Measure the desired powder load using a digital or beam scale.
- Adjust the bushing as needed to achieve the correct powder volume for your rounds.
- Once the bushing is adjusted, proceed to load the powder into the casing as per your reloading instructions.
- After use, clean the bushing with a dry cloth to remove any residue.

Disposal Instructions

- Dispose of any damaged or worn bushings in accordance with local waste disposal regulations.
- Do not throw powder bushings in regular household waste.
- Check with local authorities for specific disposal instructions related to reloading components.

Contact Information for Further Support

For any inquiries or further information regarding the MEC Powder Bushings #17, please refer to the manufacturer's official website or contact the designated EUbased support channels.

Thank you for your attention to these safety guidelines. Your safety is our priority. Enjoy your reloading experience!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at