

MEC POWDER BUSHINGS - #19 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [#19 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749009399
- Mfr. No.: 5019
- Size: #19
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 098489016223

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings #19 Safety Instruction Guide
- About Us

MEC Powder Bushings #19 Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushings #19. This safety instruction guide is designed to help you use this product safely and effectively, in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always check for any visible damage or defects before using the bushing.
- Keep the product out of reach of children and vulnerable individuals.
- Use appropriate protective equipment, such as safety glasses and gloves, when handling powder.
- Follow all manufacturer instructions and guidelines when using the product.
- Report any accidents or unsafe conditions to the relevant authorities.

Specific Safety Precautions for Use

- Use a scale to measure powder weights accurately to avoid overloads.
- Ensure that the powder bushing is securely attached to the reloading press before use.
- Never exceed the recommended powder load for your specific application.
- Store powder and bushings in a cool, dry place, away from direct sunlight and heat sources.
- Do not mix different types of powders unless specified by the manufacturer.
- Always work in a wellventilated area to minimize inhalation of powder dust.

Instructions for Installation and Usage

1. Installation:

- Ensure that the reloading press is turned off and unplugged during installation.
- Select the appropriate MEC powder bushing for your desired load.
- Attach the bushing to the reloading press according to the manufacturer's instructions.
- Secure the bushing firmly to prevent any movement during operation.

2. Usage:

- Place the scale on a stable surface and turn it on.
- Use a clean, dry container to hold the powder.
- Carefully pour the desired amount of powder into the bushing.
- Activate the reloading press to dispense the powder into the container.
- Weigh the dispensed powder to ensure it meets your specifications.
- If necessary, adjust the bushing and repeat the process until you achieve the desired load.

Disposal Instructions

- Dispose of any unused powder according to local regulations regarding hazardous materials.
- Do not dispose of powder in regular trash or down the drain.
- Recycle the packaging materials in accordance with local recycling guidelines.
- Ensure that all materials are stored safely until disposal.

Contact Information for Further Support

For any questions or concerns regarding the MEC Powder Bushings #19, please refer to the manufacturer's website or contact your local dealer for assistance. Make sure to follow the guidelines provided to ensure safe usage and compliance with safety regulations.

Thank you for prioritizing safety while using the MEC Powder Bushings #19.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at