

MEC POWDER BUSHINGS - #20 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [#20 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749009400
- Mfr. No.: 5020
- Size: #20
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 098489013000

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [MEC Powder Bushings #20 Safety Instruction Guide](#)
- [About Us](#)

MEC Powder Bushings #20 Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushings #20. This guide provides essential safety instructions to ensure the safe use of the product. Please read this manual carefully before use to understand the safety guidelines, precautions, and proper handling of the powder bushing.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep out of reach of children and vulnerable individuals.
- Always use a scale to check powder weights for accuracy.
- Regularly inspect the bushing for any signs of wear or damage before use.
- Follow all manufacturer instructions and recommendations for safe operation.

Specific Safety Precautions for Use

- **Hazard Identification:**
 - Risk of inaccurate powder loads if the bushing is not used correctly.
 - Potential for injury if the bushing is damaged or mishandled.
- **Avoiding Hazards:**
 - Always verify the bushing size and compatibility with your reloading press.
 - Do not exceed the recommended powder load limits.
 - Avoid using the bushing if it shows any signs of damage or wear.
 - Store the bushings in a dry and safe place to prevent accidental damage.

Instructions for Installation and Usage

1. **Installation:**
 - Ensure the reloading press is turned off and unplugged before installation.
 - Locate the appropriate slot for the powder bushing on your reloading press.
 - Insert the #20 powder bushing into the designated slot, ensuring it is securely in place.
2. **Usage:**
 - Before loading powder, doublecheck that the bushing is correctly installed.
 - Use a scale to measure the powder load accurately.
 - Adjust the powder load as necessary by selecting the appropriate bushing size.
 - After use, remove the bushing and clean it according to the manufacturer's instructions.

Disposal Instructions

- Dispose of the MEC Powder Bushing responsibly and in accordance with local regulations.
- Do not throw the bushing in regular household waste if it is damaged or no longer usable.
- Consider recycling options for any materials that can be repurposed.

Contact Information for Further Support

For safety inquiries or further information regarding the MEC Powder Bushings, please refer to the official MEC website or contact your local dealer.

By following these guidelines, you can ensure a safe and effective experience with your MEC Powder Bushings #20. Thank you for prioritizing safety and compliance with EU General Product Safety Regulations.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at