

MEC POWDER BUSHINGS - #34 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [#34 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749010727
- Mfr. No.: 5034
- Size: #34
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 098489015370

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings #34 Safety Instruction Guide
- About Us

MEC Powder Bushings #34 Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushings #34. This guide provides essential safety instructions to ensure the safe use of this product. Please read the entire guide carefully before using the product.

General Safety Guidelines

- Always use the MEC Powder Bushings in accordance with the manufacturer's instructions.
- Ensure that the bushing is compatible with your reloading press and the specific powder you are using.
- Check for any visible damage to the bushing before use. Do not use a damaged bushing.
- Keep the product out of reach of children and vulnerable individuals.
- Always store the bushings in a dry and safe place to prevent accidental damage or misuse.
- Regularly check for updates on safety recalls or alerts related to this product.

Specific Safety Precautions for Use

- Use a scale to measure powder weights accurately. This is crucial for safe reloading practices.
- Ensure that the bushing is properly seated in the reloading press before use to prevent powder leakage.
- Avoid overloading the bushing beyond its rated capacity. Refer to the MEC website for guidance on recommended powder loads.
- Use protective eyewear when handling powders to protect against potential dust or splashes.
- Always work in a wellventilated area to minimize inhalation of powder particles.
- If you experience any adverse reactions or accidents while using the product, seek medical attention immediately.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Select the appropriate MEC powder bushing for your desired load.
- Insert the bushing into the designated slot of your reloading press until it is firmly seated.
- Doublecheck that the bushing is secure before proceeding.

2. Usage:

- Measure the desired amount of powder using a scale.
- Pour the powder into the bushing carefully to avoid spills.
- Follow the reloading press instructions for operating the machine with the installed bushing.
- After use, clean the bushing to remove any residual powder and store it properly.

Disposal Instructions

- Dispose of any unused or expired powders according to local regulations.
- Do not dispose of bushings in household waste. Check with local recycling programs for proper disposal methods.
- If the bushing is damaged beyond use, dispose of it in a safe manner to prevent injury.

Contact Information for Further Support

For any inquiries regarding the MEC Powder Bushings #34 or for reporting safety concerns, please refer to the MEC website or your local MEC distributor for assistance.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at