

MEC POWDER BUSHINGS - #35 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [#35 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749010730
- Mfr. No.: 5035
- Size: #35
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 098489013147

Item details

Made in USA

Table of Contents

- Startpage
- MEC POWDER BUSHINGS #35 POWDER BUSHING Safety Instruction Guide
- About Us

MEC POWDER BUSHINGS #35 POWDER BUSHING Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushing #35. This product is designed to help you adjust the powder load for your reloading rounds, ensuring accuracy and efficiency. It is essential to follow the safety guidelines provided in this document to ensure safe use and compliance with applicable regulations.

General Safety Guidelines

- Always use a scale to check powder weights for accuracy.
- Store powder bushings in a cool, dry place away from direct sunlight and moisture.
- Keep powder bushings out of reach of children and pets.
- Regularly inspect your powder bushings for any signs of damage or wear.
- Always follow the manufacturer's instructions for usage and maintenance.

Specific Safety Precautions for Use

- Ensure that the bushing is securely attached to your reloading press before use.
- Avoid overloading the bushing beyond its specified capacity.
- Use the appropriate bushing size for the specific powder you are using.
- Do not attempt to modify or alter the bushing in any way.
- If you experience any issues during use, stop immediately and consult the manufacturer's guidelines.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged.
- Remove any existing bushing from the press.
- Select the appropriate MEC powder bushing for your needs.
- Insert the bushing into the designated slot on the reloading press, ensuring it fits snugly.
- Secure the bushing in place according to the manufacturer's instructions.

2. Usage

- Before each use, check the bushing for any signs of damage or wear.
- Measure out the powder using a scale to ensure you are using the correct amount.
- Follow the recommended load data for your specific powder type.
- After use, clean the bushing to remove any powder residue.

Disposal Instructions

- Dispose of any damaged or worn bushings in accordance with local regulations.
- Do not throw bushings in regular household waste if they contain any residual powder.
- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or usage of the MEC Powder Bushing #35, please refer to the manufacturer's contact information available on the MEC website.

Conclusion

By following these safety guidelines, you can ensure a safe and effective reloading experience with your MEC Powder Bushing #35. Always prioritize safety and refer to the manufacturer's instructions for any specific concerns or questions. Thank you for your attention to these important safety practices.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at