STANDARD BULLET SEATING MICROMETERS - #14 STANDARD BULLET SEATING MICROMETER

Redding Competition Seating Dies deliver the precision and accuracy preferred by the most discriminating handloaders. Now you can easily covert your conventional seating die to a precision micrometer seating die for use with STD (standard) bullets for precise, repeatable bullet seating depths to within 1/1000th of an inch and potential world-record accuracy. Designed for all seating dies that use a seat plug with ½-20 threads. Easily changes from one die to another, just match the number on your current seating plug to the corresponding bullet seating micrometer number. View Redding Micrometer Reference Chart here.

NO IMAGE AVAILABLE

Attributes

• Name: #14 STANDARD BULLET SEATING MICROMETER

Manufacturer: REDDINGProduct no.: 749017206

Mfr. No.: 09074Cartridge: -

Delivery weight: 0.079kg
Shipping height: 19mm
Shipping width: 19mm
Shipping length: 114mm
UPC: 611760090745

Item details

Made in USA

Table of Contents

- Startpage
 English: Safety Instructions for STANDARD BULLET SEATING MICROMETERS #14

Safety Instructions for STANDARD BULLET SEATING MICROMETERS #14

Introduction

Thank you for choosing the Redding STANDARD BULLET SEATING MICROMETERS #14. This product is designed to enhance your reloading experience by providing precision and accuracy in bullet seating. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always ensure that the micrometer is compatible with your seating die before use.
- Keep the micrometer and all reloading tools out of reach of children and pets.
- Inspect the micrometer for any damage or wear before each use.
- Use the micrometer only for its intended purpose as specified in this guide.
- Follow all local laws and regulations regarding ammunition reloading.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Handle the micrometer with care to avoid dropping or damaging it.
- Always wear appropriate safety gear, such as safety glasses and gloves, when reloading ammunition.
- Do not use the micrometer in wet or humid conditions to prevent corrosion.
- Ensure that your work area is welllit and free from distractions while using the micrometer.
- Avoid using excessive force when adjusting the micrometer to prevent damage.

Instructions for Installation and Usage

1. Installation

- Ensure your seating die is clean and free of debris.
- Remove the existing seating plug from your seating die by turning it counterclockwise.
- Align the threads of the micrometer with the seating die and carefully screw it in clockwise until secure.
- Match the number on your current seating plug with the corresponding bullet seating micrometer number for accurate depth adjustments.

2. Usage

- Set the desired bullet seating depth by rotating the micrometer knob. Each click represents a precise adjustment.
- Insert the bullet into the case and place it in the seating die.
- Slowly lower the ram to seat the bullet. Monitor the micrometer reading to ensure the depth is correct.
- After seating the bullet, check the depth with a caliper for confirmation.
- If adjustments are needed, repeat the process as necessary.

Disposal Instructions

- Dispose of the micrometer in accordance with local regulations.
- Do not throw the micrometer in regular household waste.
- If the micrometer is damaged beyond repair, contact a recycling facility that accepts metal products.

Contact Information for Further Support

For any questions or concerns regarding the usage or safety of the STANDARD BULLET SEATING MICROMETERS #14, please refer to the manufacturer's website or contact your local distributor.

Thank you for prioritizing safety in your reloading practices. Enjoy the precision and accuracy that the Redding STANDARD BULLET SEATING MICROMETERS #14 brings to your handloading experience.