

STANDARD BULLET SEATING MICROMETERS - REDDING #16

STANDARD BULLET SEATING MICROMETER

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Redding Competition Seating Dies deliver the precision and accuracy preferred by the most discriminating handloaders. Now you can easily convert your conventional seating die to a precision micrometer seating die for use with STD (standard) bullets for precise, repeatable bullet seating depths to within 1/1000th of an inch and potential world-record accuracy. Designed for all seating dies that use a seat plug with ½-20 threads. Easily changes from one die to another, just match the number on your current seating plug to the corresponding bullet seating micrometer number. View Redding Micrometer Reference Chart [here](#).

NO IMAGE
AVAILABLE

Attributes

- Name: [REDDING #16 STANDARD BULLET SEATING MICROMETER](#)
- Manufacturer: [REDDING](#)
- Product no.: 749017208
- Mfr. No.: 09076
- Delivery weight: 0.077kg
- Shipping height: 19mm
- Shipping width: 19mm
- Shipping length: 114mm
- UPC: 611760090769

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Redding #16 Standard Bullet Seating Micrometer](#)
- [About Us](#)

Safety Instruction Guide for Redding #16 Standard Bullet Seating Micrometer

Introduction

Thank you for choosing the Redding #16 Standard Bullet Seating Micrometer. This product is designed to enhance your handloading experience by providing precision and accuracy in bullet seating. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that all users are familiar with the product and its intended use.
- Always wear appropriate safety gear, including eye protection, when using reloading equipment.
- Keep the micrometer and all reloading tools out of reach of children and vulnerable individuals.
- Regularly inspect the micrometer for any signs of damage or wear before each use.
- Follow all manufacturer instructions and guidelines for use and maintenance.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Do not exceed the recommended seating depth as specified by your bullet manufacturer.
- Always ensure the micrometer is securely attached to the seating die before use.
- Avoid using the micrometer in wet or damp conditions to prevent corrosion or malfunction.
- Never use excessive force when adjusting the micrometer settings; this may cause damage.
- Ensure that your work area is clean and free from obstructions to prevent accidents.
- If you experience any issues while using the micrometer, stop immediately and consult the troubleshooting section of the product manual.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged (if applicable).
- Remove the existing seating plug from your seating die.
- Align the Redding #16 Standard Bullet Seating Micrometer with the threads of your seating die.
- Securely screw the micrometer into place, ensuring it is tight but not overtorqued.

2. Usage:

- Set the desired bullet seating depth by adjusting the micrometer dial.
- Insert a bullet into the case and place it in the seating die.
- Pull the handle of your reloading press to seat the bullet.
- Measure the seating depth with calipers to ensure accuracy.
- Repeat the process as necessary, adjusting the micrometer for different bullet types or depths.

Disposal Instructions

- Dispose of the micrometer in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the micrometer is damaged or no longer usable, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Redding #16 Standard Bullet Seating Micrometer, please refer to the product manual or contact the manufacturer directly. Ensure you have your product details ready for efficient support.

Thank you for your attention to these safety instructions. Enjoy your handloading experience with the Redding #16 Standard Bullet Seating Micrometer.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk