

MEC LEAD CHARGE BAR PROGRESSIVE PRESS - MEC RELOADING 1/2OZ LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses. Steel shot bars are available by special order.



Attributes

- Name: [MEC RELOADING 1/2OZ LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019417
- Mfr. No.: 50212
- Size: 1/2 oz
- Delivery weight: 0.249kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 159mm
- UPC: 098489013727

Item details

Made in USA

Table of Contents

- Startpage
- MEC Lead Charge Bar Progressive Press Safety Instructions
- About Us

MEC Lead Charge Bar Progressive Press Safety Instructions

Introduction

Thank you for choosing the MEC Lead Charge Bar Progressive Press. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully before using the charge bar.

General Safety Guidelines

- Always use the MEC Lead Charge Bar in accordance with the manufacturer's instructions.
- Ensure that the work area is clean and free from distractions while reloading.
- Keep the charge bar and all reloading components out of reach of children and unauthorized users.
- Wear appropriate safety gear, including eye protection, when using the reloading press.
- Regularly inspect the charge bar for signs of wear or damage before use.

Specific Safety Precautions for Use

- Do not exceed the recommended load limits for the charge bar. The MEC Lead Charge Bar is designed for a maximum charge of 1/2 oz.
- Ensure that the charge bar is securely attached to the reloading press before use.
- Avoid using the charge bar with incompatible materials. The steel shot bars are available by special order and should be used only as specified.
- Be cautious of any potential hazards associated with the materials being loaded, such as lead dust or other particulates.
- In case of any malfunction or unusual operation, stop using the charge bar immediately and consult the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged before installation.
- Remove the existing charge bar from the press.
- Align the MEC Lead Charge Bar with the mounting points on the reloading press.
- Securely attach the charge bar using the provided hardware. Ensure it is fastened tightly.
- Doublecheck the installation to confirm that the charge bar is properly positioned.

2. Usage:

- Set the desired load by adjusting the charge bar according to the manufacturer's guidelines.
- Load the appropriate materials into the charge bar.
- Operate the reloading press slowly and steadily to ensure consistent results.
- Monitor the operation closely to detect any issues or irregularities.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Lead shot and other materials should be disposed of at designated recycling or hazardous waste facilities.
- Do not dispose of the charge bar or its components in regular household waste.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please reach out to the manufacturer or your local distributor. It is important to have a clear channel for addressing safety concerns.

By following these instructions and guidelines, you can ensure a safe and effective reloading experience with the MEC Lead Charge Bar Progressive Press. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk