

MEC POWDER BUSHINGS - MEC RELOADING #11 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [MEC RELOADING #11 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019447
- Mfr. No.: 5011
- Delivery weight: 0.016kg
- Shipping height: 19mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489013437

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings Safety Instruction Guide
- About Us

MEC Powder Bushings Safety Instruction Guide

Introduction

Thank you for choosing MEC Powder Bushings for your reloading needs. This guide provides essential safety instructions to ensure the safe use of these products. Please read this document carefully before using the bushings to ensure your safety and the safety of others.

General Safety Guidelines

- Always ensure that you are using the correct powder bushing for your specific powder and load requirements.
- Store powder bushings in a cool, dry place away from direct sunlight and moisture.
- Regularly inspect your powder bushings for any signs of wear or damage. Do not use damaged bushings.
- Keep all reloading components, including powder and bushings, out of reach of children and pets.
- Follow all local laws and regulations regarding the storage and use of reloading materials.

Specific Safety Precautions for Use

- Always use a scale to check powder weights for accuracy before loading ammunition.
- Never exceed the recommended powder load for your specific bushing.
- Avoid using bushings that are not compatible with your reloading press or equipment.
- Be aware of the potential hazards associated with handling gunpowder and follow all safety protocols.
- Wear safety glasses and protective gear when handling reloading components.

Instructions for Installation and Usage

1. Installation of Powder Bushing:

- Ensure your reloading press is turned off and unplugged.
- Remove the existing bushing from the press if applicable.
- Carefully insert the desired MEC powder bushing into the press, ensuring it fits securely.
- Doublecheck that the bushing is properly seated before proceeding.

2. Using the Powder Bushing:

- Set your scale to zero and place an empty container on it.
- Use the bushing to dispense powder into the container, ensuring to follow the recommended load.
- Weigh the powder to confirm it matches the desired load.
- If adjustments are necessary, switch to a different bushing or make adjustments as per manufacturer recommendations.

3. PostUse Care:

- After use, clean the bushing to remove any residual powder.
- Store the bushing in its original packaging or a safe container to prevent damage.

Disposal Instructions

- Dispose of any used or damaged powder bushings in accordance with local regulations.
- Do not discard powder bushings in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or assistance regarding MEC Powder Bushings, please refer to the MEC website or contact the designated EUbased support service.

Thank you for prioritizing safety in your reloading practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk