

MEC POWDER BUSHINGS - MEC RELOADING #12 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [MEC RELOADING #12 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019448
- Mfr. No.: 5012
- Size: -
- Delivery weight: 0.016kg
- Shipping height: 19mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489015820

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings Safety Instruction Guide
- About Us

MEC Powder Bushings Safety Instruction Guide

Introduction

Thank you for choosing MEC Powder Bushings for your reloading needs. This guide provides essential safety instructions to ensure the safe and effective use of your MEC Powder Bushings. Please read this guide carefully before using the product.

General Safety Guidelines

- Always ensure that your workspace is clean and free from distractions when reloading.
- Keep all components, including powder bushings, out of reach of children and pets.
- Use protective eyewear and gloves when handling reloading materials.
- Store powder and reloading components in a cool, dry place, away from direct sunlight.
- Regularly inspect your powder bushings for wear or damage before each use.
- Follow the manufacturer's recommendations for load specifications and adjustments.

Specific Safety Precautions for Use

- Ensure that the correct bushing is selected for the powder type and load you are using.
- Never exceed the recommended powder load as specified in the MEC charts.
- Always use a reliable scale to verify powder weights for accuracy.
- Do not mix different types of powders in the same bushing.
- If you notice any unusual behavior during the reloading process, stop immediately and assess the situation.
- Be cautious when adjusting the powder load; make small adjustments and recheck weights frequently.

Instructions for Installation and Usage

1. Installation of Powder Bushing

- Ensure your reloading press is turned off and unplugged before installation.
- Remove the existing bushing from the press.
- Select the appropriate MEC Powder Bushing based on the desired powder load.
- Insert the new bushing securely into the press according to the manufacturer's instructions.

2. Using the Powder Bushing

- Prepare your reloading station with all necessary equipment.
- Measure the desired amount of powder using the selected bushing.
- Use a scale to confirm the weight of the powder before proceeding.
- Load the powder into the cartridge case carefully, ensuring no spillage occurs.
- After use, clean the bushing to prevent residue buildup.

Disposal Instructions

- Dispose of used powder bushings and any reloading components in accordance with local regulations.
- Do not throw used powder or hazardous materials in regular trash.
- Contact local waste management services for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding MEC Powder Bushings, please refer to the manufacturer's website

or customer service for assistance.

By following these safety guidelines and instructions, you can ensure a safe reloading experience with MEC Powder Bushings. Always prioritize safety and stay informed about best practices in reloading. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk