

MEC POWDER BUSHINGS - MEC RELOADING #38 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mecreloaders.com



Attributes

- Name: [MEC RELOADING #38 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019455
- Mfr. No.: 5038
- Size: -
- Delivery weight: 0.009kg
- Shipping height: 19mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489010511

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [MEC Powder Bushings Safety Instruction Guide](#)
- [About Us](#)

MEC Powder Bushings Safety Instruction Guide

Introduction

Thank you for choosing MEC Powder Bushings. This guide provides essential safety information to ensure the safe and effective use of our products. Please read this guide carefully before using the powder bushings to minimize risks and enhance your reloading experience.

General Safety Guidelines

- Ensure safe handling and use of all MEC Powder Bushings.
- Always verify that the bushing you are using is compatible with your specific reloading setup.
- Keep all powder bushings out of reach of children and vulnerable individuals.
- Regularly check for updates on product recalls and safety information through official channels.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always use a reliable scale to measure powder loads for accuracy.
- Do not exceed the recommended powder load for your specific bushing.
- Inspect the bushing for any damage or wear before each use.
- Avoid using bushings that show signs of deterioration, as they may affect performance and safety.
- Store powder bushings in a cool, dry place away from direct sunlight and moisture.
- Follow all manufacturer guidelines for the specific powder you are using.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove the existing bushing from the press if applicable.
- Select the appropriate MEC Powder Bushing for your desired powder load.
- Insert the new bushing securely into the reloading press, ensuring it fits snugly.

2. Usage:

- Turn on the reloading press and ensure it is functioning correctly.
- Set the scale to zero before adding powder to the bushing.
- Gradually add powder until the desired weight is achieved, using the scale to verify.
- If the weight is not correct, adjust the bushing as needed and repeat the measurement.
- After use, clean the bushing to remove any powder residue and ensure accurate measurements in the future.

Disposal Instructions

- Dispose of any damaged or worn powder bushings in accordance with local regulations.
- Do not dispose of bushings in general waste if they contain residual powder.
- Contact local waste management services for guidance on safe disposal methods.

Contact Information for Further Support

For any safety inquiries, please refer to the MEC website or your local retailer for assistance and support related to MEC Powder Bushings.

By following these safety instructions, you can ensure a safe and effective reloading experience with MEC Powder Bushings. Always prioritize safety and stay informed about best practices in reloading.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk