

MEC POWDER BUSHINGS - MEC RELOADING #38A POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at www.mcreloaders.com



Attributes

- Name: [MEC RELOADING #38A POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019456
- Mfr. No.: 5038A
- Delivery weight: 0.009kg
- Shipping height: 19mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489015295

Item details

Made in USA

Table of Contents

- Startpage
- MEC Powder Bushings Safety Instruction Guide
- About Us

MEC Powder Bushings Safety Instruction Guide

Introduction

Thank you for choosing the MEC Powder Bushings. These accessories are designed to help you achieve precise powder loads for your reloading needs. This guide provides essential safety instructions to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand the manufacturer's instructions before use.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose.
- Regularly check for any signs of wear or damage before use.
- Report any unsafe conditions or incidents to the relevant authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure you are using the correct bushing size for your specific powder load.
- Always weigh powder loads using a reliable scale for accuracy.
- Avoid overloading your reloading equipment, which can lead to dangerous situations.
- Do not use the powder bushings in combination with incompatible materials or products.
- Wear appropriate safety gear, such as safety glasses, when reloading.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing bushings from the reloading press.
- Select the appropriate MEC powder bushing based on your powder load requirements.
- Insert the selected bushing securely into the reloading press, ensuring it is properly seated.

2. Usage:

- Prepare your workspace to be clean, dry, and free from distractions.
- Measure the desired amount of powder using a scale.
- Set the powder bushing to the correct setting based on the powder chart provided on the MEC website.
- Carefully dispense the powder into your reloading case, ensuring no spills occur.
- After use, clean the bushing to prevent powder residue buildup.

Disposal Instructions

- Dispose of any damaged or wornout powder bushings in accordance with local regulations.
- Recycle packaging materials where possible.
- Do not dispose of powder or reloading materials in regular household waste. Follow local hazardous waste disposal guidelines.

Contact Information for Further Support

For any inquiries related to the safety and use of MEC Powder Bushings, please refer to the official MEC website

or contact your local MEC dealer.

By following these guidelines, you can ensure a safe and effective reloading experience with MEC Powder Bushings. Always prioritize safety and stay informed about best practices in reloading.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk