

# MEC POWDER BUSHINGS - MEC RELOADING #42 POWDER BUSHING

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

We stock a variety of the MEC powder bushings. Each bushing holds a unique volume enabling you to adjust the powder load for your rounds. It is always recommended to use a scale to check powder weights for accuracy. We offer individual bushings in #7 thru #13 and #16 thru #38. Please refer to the MEC website for powder charts that will give you a recommended bushing and start point for your specific powder at [www.mecreloaders.com](http://www.mecreloaders.com)



## Attributes

- Name: [MEC RELOADING #42 POWDER BUSHING](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019463
- Mfr. No.: 5042
- Size: -
- Delivery weight: 0.007kg
- Shipping height: 19mm
- Shipping width: 114mm
- Shipping length: 186mm
- UPC: 098489012638

## Item details

Made in USA

# Table of Contents

- Startpage
- MEC Powder Bushings Safety Instruction Guide
- About Us

# MEC Powder Bushings Safety Instruction Guide

## Introduction

Thank you for choosing the MEC Powder Bushings. This guide provides essential safety instructions to ensure the safe use of these products. Please read this guide carefully before using the MEC Powder Bushings to ensure safe and effective operation.

## General Safety Guidelines

- Always ensure that you are using the correct powder bushing for your specific powder type.
- Use a scale to check powder weights for accuracy.
- Store powder bushings in a cool, dry place away from direct sunlight and moisture.
- Keep powder bushings out of reach of children and pets.
- Regularly inspect the bushings for any signs of wear or damage before use.
- If you experience any issues or are unsure about the use of the product, seek assistance from a qualified professional.

## Specific Safety Precautions for Use

- Ensure that the reloading press is properly set up and secured before installing the powder bushing.
- Do not exceed the recommended powder load for your specific bushing.
- Avoid using any powder that is not compatible with your reloading setup.
- Be mindful of static electricity when handling powders; use antistatic measures if necessary.
- Always follow the manufacturer's instructions for your specific reloading equipment.
- In case of spillage, clean up immediately and dispose of powder according to local regulations.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that the reloading press is turned off and unplugged.
- Remove any existing bushing from the press.
- Select the appropriate MEC powder bushing based on the desired powder load.
- Insert the new bushing into the press securely.
- Doublecheck that the bushing is properly seated before proceeding.

### 2. Usage:

- Measure the required amount of powder using a scale.
- Pour the measured powder into the bushing.
- Cycle the reloading press to dispense the powder into the shell.
- After use, clean the bushing and store it properly.

## Disposal Instructions

- Dispose of any unused or expired powders according to local hazardous waste regulations.
- Do not throw powder bushings in regular trash; check with local recycling facilities for proper disposal options.
- Ensure that all materials are disposed of in a manner that prevents environmental contamination.

## **Contact Information for Further Support**

For further support or inquiries regarding safety, please contact the manufacturer or visit the official MEC website for more information.

By following these guidelines, you can ensure a safe and effective reloading experience with the MEC Powder Bushings. Thank you for your attention to safety!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)